



INSTALLATION INFO for DNA TC-H75SC21-S2

Application: HONDA X-ADV 750, FORZA 750, NC 750 X 21'

The **DNA High Performance Filters Stage 2 application TC-H75SC21-S2** is designed to replace the stock HONDA plastic air box cover in combination with Stage 1 application **P-H75SC21-01 (SOLD SEPARATELY)**, and increase the airflow, filtering efficiency, Power and Torque.

1. Remove the stock air box cover and the air filter from the bike, following the instructions found in the official HONDA workshop manual.
Be very careful when removing the stock filter, so debris doesn't fall in the clean side of the air box.
2. Install the DNA High Performance Filter P-H75SC21-01 (SOLD SEPARATELY).
3. Install the DNA Stage 2 frame and use the supplied 8 bolts included in the kit.
4. Remove the OEM temperature sensor and install it on the DNA frame with the supplied 2 bolts and 2 nuts.

Follow the above procedure each time you need to remove the DNA filter for servicing it.
Service every **15.000 km** or earlier when used in extremely dusty environment.

Use the dedicated DNA Service Kit **DSK-3001** (sold separately) to clean and re-oil, following the instructions included with the service kit.
The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein.
Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.

www.dnafilts.com, www.facebook.com/dnafilts, www.instagram.com/dnafilts, www.youtube.com/dnafilts, techsupport@dnafilts.com