

INSTALLATION INFO for DNA TC-BM18CR20-S2 & P-BM18CR20-S2 COMBO

Application: BMW R18 20'-21'

The DNA High Performance Stage 2 air box cover TC-BM18CR20-S2 is designed to replace the stock plastic air box cover. Combined with the DNA High Performance Filter P-BM18CR20-01 (sold separately or in Combo with the filter) will increase the Airflow, filtering efficiency, Power, Torque and Throttle response.

TC-BM18CR20-S2 ↓



P-BM18CR20-S2 COMBO ↓



1. Remove the stock air filter and cover, be very careful when removing the stock filter and cover so debris doesn't fall in the clean side of the air box.
Attention: the plastic OEM cover will **NOT** be used anymore.



2. Install the DNA air filter and on top the Stage 2 Air Box Cover. Bolt the frame in place with the inox TX25 torx bolts provided in the kit. Do not overtighten the bolts, torque at 0,8 kgm!
3. If the intalation is correct it should look as following:



- Follow the above procedure each time you need to remove the DNA filter for servicing it.
- Service every 15.000 km or earlier when used in extremely dusty environment.

Use the dedicated DNA Service Kit DSK-3001 (sold separately) to clean and re-oil, following the instructions included with the service kit.

Attention! Product is designed for CUSTOMIZED Bikes. In some countries it may be illegal to use on public roads.

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein.

Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.

www.dnafilts.com, www.facebook.com/dnafilts, www.instagram.com/dnafilts, www.youtube.com/dnafilts, techsupport@dnafilts.com

INSTALLATION INFO for DNA TC-BM18CR20-S2 & P-BM18CR20-S2 COMBO

Application: BMW R18 20'-21'

The DNA High Performance Stage 2 air box cover TC-BM18CR20-S2 is designed to replace the stock plastic air box cover. Combined with the DNA High Performance Filter P-BM18CR20-01 (sold separately or in Combo with the filter) will increase the Airflow, filtering efficiency, Power, Torque and Throttle response.

TC-BM18CR20-S2 ↓



P-BM18CR20-S2 COMBO ↓



1. Remove the stock air filter and cover, be very careful when removing the stock filter and cover so debris doesn't fall in the clean side of the air box.
Attention: the plastic OEM cover will **NOT** be used anymore.



2. Install the DNA air filter and on top the Stage 2 Air Box Cover. Bolt the frame in place with the inox TX25 torx bolts provided in the kit. Do not overtighten the bolts, torque at 0,8 kgm!
3. If the intalation is correct it should look as following:



- Follow the above procedure each time you need to remove the DNA filter for servicing it.
- Service every 15.000 km or earlier when used in extremely dusty environment.

Use the dedicated DNA Service Kit DSK-3001 (sold separately) to clean and re-oil, following the instructions included with the service kit.

Attention! Product is designed for CUSTOMIZED Bikes. In some countries it may be illegal to use on public roads.

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein.

Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.

www.dnafilts.com, www.facebook.com/dnafilts, www.instagram.com/dnafilts, www.youtube.com/dnafilts, techsupport@dnafilts.com